SLIDE

Proper Mold Care At The Machine

Mold Cleaners

Mold cleaner removes resin deposits. Mold cleaning wipes are placed at every station for a convenient quick wipe-down.



Lubricants Dozens of ejector pins require periodic lubrication. Pick a lubricant that won't mark the plastic parts.



Rust Preventives Rust appears in just hours on idle molds. Rust preventive is applied for overnight protection and when the mold is moved to the shop to wait for maintenance.

Condensation appears

during cool-down. Rust preventive displaces moisture and neutralizes fingerprint acids.

Mold Releases Mold release is sprayed over the entire mold or just spots where the plastic part tends to stick or hang up.



Great Solutions Under Pressure • www.plastixs.com

Over 6 Decades of Mold Care Experience

Slide Products is distributed by



The platen holds the mold.

Water is used to control mold temperature.