


HOW TO MEASURE FOR ISOCOVERS ISO-HUB:

Selecting the right size ISOCOVERS ISO-HUB for your machine is a lot easier than you might think. All you need is a tape measure, and you are ready to go!

1. Measure for either the (1) CIRCUMFERENCE OR (2) DIAMETER:



CIRCUMFERENCE

OR



DIAMETER

NOTE: It does not matter which method of measurement you decide to use, just remember that you only need to find your measurement using one of the two ways mentioned above.

2. Measure for the DESIRED WIDTH:



WIDTH

NOTE: After measuring either the circumference or diameter, you also need to measure for the desired width to determine the width of the application you want to insulate.

WARNING: When installing or measuring for ISO-HUB, please follow all safety precautions and use proper and adequate protective safety aids such as: protective gloves and suitable protective clothing. Never use a metal tape for measuring purposes. Failure to do so may result in injury.

3. Find the right ISOCOVERS ISO-HUB:

NOTE: Now that you have your measurements, you can use the graph below to help you find the appropriate ISOCOVERS ISO-HUB part number. Diameter and circumference (length) measurements are listed in the table rows vertically and width measurements are listed in the table columns horizontally.

		WIDTH	
CIRCUMFERENCE	DIAMETER	6in (152mm)	12in (305mm)
0in - 6in (0mm-152mm)	0in-2in (0mm-60mm)	IH 0206	IH 0212
6in-13in (152mm-330mm)	2in-4in (60mm-102mm)	IH 0406	IH 0412
13in-19in (330mm-483mm)	4in-6in (102mm-152mm)	IH 0606	IH 0612
19in-25in (483mm-635mm)	6in-8in (152mm-203mm)	IH 0806	IH 0812
25in-31in (635mm-787mm)	8in-10in (203mm-254mm)	IH 1006	IH 1012
31in-38in (787mm-965mm)	10in-12in (254mm-305mm)	IH 1206	IH 1212
38in-44in (965mm-1118mm)	12in-14in (305mm-356mm)	IH 1406	IH 1412
44in-50in (1118mm-1270mm)	14in-16in (356mm-406mm)	IH 1606	IH 1612
50in-57in (1270mm-1448mm)	16in-18in (406mm-457mm)	IH 1806	IH 1812

The **CIRCUMFERENCE** (length) is 23in and the desired width is 9in = **IH 0812**.
OR
The **DIAMETER** (length) is 8in and the desired width is 9in = **IH 0812**.